



# Assembly Instructions

## Universal slip repair coupler

1



Mark pipe insertion depth

2



Insert the pipe

3



Tighten the nut